

Dreamtale

Input List

Patch	*	CH	+48V		Input / DI	Insert	Mic stands
		1		BD	e602-II	exp/comp	Short boom
	7	2		BD Trigger	D.I	exp/comp	
		3		Snare	e604	exp/comp	N/N
		4		Tom 1	e604	gate	N/N
		5		Tom 2	e604	gate	N/N
		6		Tom 3	e604	gate	N/N
		7		Tom 4	e604	gate	N/N
		8	x	Overhead Left	e614		Telescope boom
		9	x	Overhead Right	e614		Telescope boom
		10		Bass	XLR		
		11	x	Keyboard L	D.I	comp	
		12	x	Keyboard R	D.I	comp	
		13		Rami GTR	XLR		
		14		Zsolt GTR	XLR		
	2	15	x	HD Left	D.I		
	3	16	x	HD Right	D.I		
		17		Nitte Vocal			N/N
		18		Jarno Vocal			N/N
		19		Rami Backing Vocal			Boom stand
		20		Zsolt Backing Vocal			Boom stand
	4	21	x	Bvox HD L	D.I		
	5	22	x	Bvox HD R	D.I		
	1	23		Click HD	D.I		
	6	24		Click A	D.I		

* Multicore HD cable: 1-23, 2-15, 3-16, 4-21, 5-22, 6-24, 7-2.

Dreamtale

Monitor / IEM Returns / Master LR

Patch	CH	Player	Instrument	Gear	In-ear Frequencies
	1-2	Arto	Drums		Cable
	3-4	Mikko	Bass	Sennheiser	626-668 MHz
	5-6	Akseli	Keyboard		Cable
	7-8	Rami	Guitar	Sennheiser	626-668 MHz
	9-10	Zsolt	Guitar	Sennheiser	626-668 MHz
	11-12	Nitte	Main Vocal	Sennheiser	626-668 MHz
	13-14	Jarno	Main Vocal	Sennheiser	626-668 MHz
	15-16	Master LR for PA	Master LR for PA		

Instrument Wireless Frequencies

CH	Player	Instrument	Gear	Frequencies
10	Mikko	Bass	Shure GLXD16+	2,4/5,8 GHz
13	Rami	Guitar	Shure GLXD16+	2,4/5,8 GHz
14	Zsolt	Guitar	Shure GLXD16	2,4 GHz
17	Nitte	Main Vocal	Sennheiser ew-Dx	470,2-550 Mhz
18	Jarno	Main Vocal	Sennheiser ew-Dx	470,2-550 Mhz